



DELTA MOTION



RMC150 Motion Controller **Startup Guide**

With wiring diagram



Where to Get Help



Video Tutorials



In RMCTools, on the **Help** menu, click **Video Tutorials**

RMCTools Help



In RMCTools, on the **Help** menu, click **Help Topics**

Forum



Visit forum.deltamotion.com

Delta Technical Support



Phone: +1-360-254-8688



Email: support@deltamotion.com

Important Information

-  **WARNING:** Using this product in a manner not specified by the manufacturer may impair the protection provided by the equipment.
-  **WARNING:** Employ safety circuits or devices external to the motion controller to ensure the machine operates safely even in the event of a failure in any part of the controller.
-  **WARNING:** If deemed necessary by a risk assessment, employ an emergency stop system to avert harm or to reduce existing hazards to persons, machinery, or work in progress.
-  **WARNING:** Use proper lock-out procedures when working on the machine to prevent injury or machine damage.
-  **WARNING:** On hydraulic systems, use blocking valves or other suitable methods to prevent the hydraulic system from moving unexpectedly when working on the machine.
-  **WARNING:** Use fuses to limit any fault currents that could cause smoke or fire due to a fault in the RMC or external device.

Contents

Step 1: Mounting.....	1
Step 2: Wiring	2
Step 3: Install RMCTools	3
Step 4: Connect RMC to PC.....	4
Step 5: Start a New Project	5
Step 6: Define the Axes.....	9
Step 7: Test an Actuator.....	11
Step 8: Test Feedback Device	14
Step 9: Scale and Offset.....	18
Step 10: Set the Output Polarity	19
Step 11: Tuning	20
Continuing the Motion Application	23
Diagnostic Tools	25
Appendix A: Wiring	26
Appendix B: Mounting Dimensions.....	39
Appendix C: Agency Compliance	40

Version 5.0, June 19, 2023


Copyright © 2023, Delta Computer Systems, Inc., also doing business as Delta Motion.

Delta Motion is a U.S. registered trademark of Delta Computer Systems, Inc.

Step 1: Mounting

The RMC should be mounted upright on a vertical surface, such that the ventilation holes are on the top and bottom.

Mounting Options



Symmetrical DIN 3



Panel-mount

See [Appendix B: Mounting Dimensions](#) for dimensions.

Clearance

The amount of clearance above and below depends on the maximum ambient temperature:

Ambient Temperature	Clearance
122 - 140°F (50 - 60°C)	3 in. (7.6 cm)
86 - 122°F (30 - 50°C)	2 in. (5.1 cm)
Less than 86°F (30°C)	1 in. (2.5 cm)

Grounding

Make sure to properly ground the RMC. If mounted on a DIN rail, the RMC will conduct to the DIN rail. The RMC shell is electrically connected to its Case pins.

Step 2: Wiring

Wire the power, actuators, and feedback devices to the RMC according to the instructions in **Appendix A: Wiring** on page 26.

Note: Remove power from the RMC before connecting any wires.

Wiring Topic	Page	
General Wiring Information	27	
Power	28	
Control Output (Drive)	28	
SSI Inputs	29	
Start/Stop and PWM Inputs (Magnetostrictive)	31	
Analog Inputs	Voltage Transducer	33
	Potentiometer	34
	Current Transducer	34
Resolver Inputs	36	
Discrete Inputs/Outputs	Discrete Outputs	37
	Discrete Inputs	38

Step 3: Install RMCTools

Download

1. Go to deltamotion.com/dloads/
2. Choose the **RMC70** or **RMC150** category, then choose the **Software** category.
3. Choose the RMCTools 32-bit or 64-bit version as required for your computer.
4. Run the rmctoolsinstall32.exe or rmctoolsinstall64.exe file and follow the instructions.

Start RMCTools

On the Windows **Start** menu, choose **All Programs** and then **RMCTools**.

PC Requirements for RMCTools

Operating System	7/8.1/10/11
------------------	-------------

Step 4: Connect RMC to PC

USB Cable


Connect a standard A to B USB cable to the PC and the RMC150E USB port .

This type of USB cable is used for PC peripherals such as printers and is available at any store that sells electronics.




Or use an Ethernet Cable

Connect an Ethernet cable to the RMC150E and the PC or Ethernet switch. The RMC150E supports both straight-through and crossover cables.




Step 5: Start a New Project


1. Start RMCTools.
2. In the **Startup** dialog, select **Create a New Project** and click **OK**.



3. Enter the **Project Name**, then click **Finish**.




4. In the **New Controller Wizard**, select **Automatically Detect the Controller Information**, then click **Next**.




5. RMC150E via USB:

- A. Click **USB** and click **Next**.



- B. When the RMC appears in the list, select it and click **Next**.



RMC150E via Ethernet:

- A. Click **Ethernet** and click **Next**.




- B. Use the MAC address (on the RMC150E label) to identify the RMC in the list, then click the RMC.



- C. If the RMC does not have an IP address (0.0.0.0), click **Configure Device**, choose **Use the following IP address**, set the **IP Address** and **Subnet Mask**, then click **OK**.

- D. Click **Next**.


6. RMCTools will connect to the RMC and display it.
Verify it is correct, then click **Finish**.



7. The toolbar now displays **Online (PROG)**. This means RMCTools is communicating with the controller.

Project Pane

The project pane contains all the items in the project. Use the Project pane to navigate through the entire project.



Set Up Universal I/O Channels

If your RMC includes a **Universal I/O** module, you must first set up the high-speed channels before using them as part of an axis.

1. In the Project pane, expand the **Modules** folder and double-click the UI/O module.
2. On the **Quad/SSI** page, choose the desired **Mode** for each channel. Typically, this will be **Quadrature Input** or **SSI Axis Input**. For more details, refer to the **UI/O module** topic in the RMCTools help.

Saving Settings



Throughout the startup procedure, make sure to save the configuration changes you make, or they may be lost!

1. Save RMCTools Project

On the **File** menu, click **Save**.

2. Update Flash

On the **Controller** menu, click **Update Flash**.



IF YOU DO NOT UPDATE FLASH, CHANGES TO THE RMC WILL BE LOST WHEN POWER IS REMOVED!

3. Repeat Often

Make sure to save often to prevent loss of data.

Tip: On the **File** menu, click **Save and Update Flash** to perform both operations at once.

Step 6: Define the Axes


To use a physical input or output, it must be assigned to an internal software axis. The RMC starts with default axis assignments which you will likely need to change.

Note: It is important to define the axes at the start of the project.
Major changes to axes later may result in lost axis parameters.

Example Axis Definitions


Position Control Axis

One Control Output, one position input.



Position-Force Control Axis (all part of a single axis)

One Control Output, one position input, dual-input force




Reference Axis

One position input.




View Axis Definitions

1. In the Project tree, expand the **Axes** folder and double-click **Axis Definitions**.



2. The **Axis Definitions** dialog opens:

The list displays the software axes. To see the assigned hardware, click an axis in the list. The hardware assigned to that axis will be highlighted in the image.



Edit Axis Definitions

Use the Axis Definitions dialog to change the axis definitions:

- Click **New** to add an axis.
- Click **Change** to edit the selected axis.
- Click **X** to remove an axis.

If you need to make significant changes to the axis definitions, first delete all the axes, then create new ones.

For more details, click the **Help** button.

Step 7: Test an Actuator


You will now test an actuator such as a hydraulic valve or a motor. You will use the Direct Output command to send a voltage to the actuator. The actuator must already have been wired to the RMC.




USE THE DIRECT OUTPUT COMMAND WITH CAUTION! IT DISABLES THE SAFETY FEATURES OF THE RMC!

Fault Controller Button

If the motion causes problems, be prepared to quickly stop the axis by clicking the **Fault Controller** button on the toolbar, or pressing Ctrl + K on the keyboard.



1. Check the machine and make sure that the axis may safely move in both directions.
2. In the Project tree, double-click **Axis Tools**.




3. In the **Axis Status Registers**, on the **Basic** tab, look at the **Control Output**.

It should be 0.


Register	Axis0	Axis1
Command Position (pu)	0.000	0.000
Target Position (pu)	0.000	0.000
Actual Position (pu)	0.000	0.000
Command Velocity (pu/s)	0.000	0.000
Target Velocity (pu/s)	0.000	0.000
Actual Velocity (pu/s)	0.000	0.000
Control Output (V)	0.000	0.000
B1: Status Bits	16#00000000	16#000012C4
C1: Error Bits	16#00000000	16#00000000
Control Output (V)	0.000	1ff

5. In the Command Tool, in the axis the actuator is connected to, click the  button.



6. Browse to **Motion Commands**, then **Open Loop**.


Choose the **Direct Output** command and click **OK**.



7. For the Direct Output command parameters, enter the following:


- **Output:** 0.1
- **Ramp Rate:** 100

When you send the command in the next step, the Control Output voltage will ramp to 0.1 V at a rate of 100 V/sec.



8. In the Command Tool, click **Send**.

The axis should move, and the **Control Output** (in the **Axis Status Registers**) should be 0.100.




9. If the axis did not move, resend the command with a larger Output until the axis moves.

Note: For the Quad module, if you are using the Enable Output for enabling the actuator, such as a motor drive, then you first need to set the Enable Output before trying to move the actuator. For details, see the **Set Enable Output (67) Command** topic in the RMCTools help.

10. Now stop the axis:

In the Command tool, enter 0 in the **Output** box and click **Send**.



11. Repeat these steps to move the axis in the other direction. In the Direct Output command, use a negative **Output**. Move the axis back and forth through the entire travel range to make sure the machine is operating properly.

Step 8: Test Feedback Device

Now that you have connected and tested an actuator, you will connect and verify a feedback device. The device must already have been wired to the RMC.

Configure Feedback


In **Axis Tools**, in the **Axis Parameters** pane, on the **Setup** tab, you will configure certain parameters depending on the type of input you are using.

Refer to the procedure for your transducer type and module:

Transducer Type	Module	Page
Start/Stop or PWM (Magnetostrictive)	MDT (M)	15
SSI (Linear or Rotary)	SSI (S), Universal I/O (UI/O)	15
Analog (Voltage or Current)	ANLG (H), ANALOG INPUTS (A), ANLG2 (G), Universal I/O (UI/O)	16
Quadrature Encoder (A, B, Z)	QUAD (Q), Universal I/O (UI/O)	16
Resolver	RESOLVER (R)	16

Start/Stop or PWM (Magnetostrictive) Feedback

1. In the **Axis Parameters**, on the **Setup** tab, set the **MDT Type** register to the type of magnetostrictive transducer you have.
This information is available from your transducer datasheet.




2. Click the **Download** button to apply the changes to the RMC.
3. Continue to the **Verify Feedback** section on page 17.

SSI Feedback

1. In the **Axis Parameters** pane, on the **Setup** tab, set the following cells.
 - **SSI Format**
 - **SSI Data bits** (e.g. 24)
 - **Linear/Rotary**

This information is available from your SSI device datasheet.




Note: For help on a parameter, click the cell and press F1.

2. Click the **Download** button to apply the changes to the RMC.
3. Continue to the **Verify Feedback** section on page 17.

Analog Feedback

1. In the **Axis Parameters**, on the **Setup** tab, set the **Input Type** to **Voltage ($\pm 10V$)**, **Voltage ($\pm 5V$)**, or **Current (4-20mA)**.

If the input is the primary input of the axis, the **Input Type** is under the **Primary Control Setup** section in the Axis Parameters.



For pressure or force inputs on a dual-loop axis, the **Input Type** is in the **Secondary Control Setup** section in the Axis Parameters.

2. Click the **Download** button  to apply the changes to the RMC.
3. Continue to the **Verify Feedback** section on page 17.

Quadrature Encoder Feedback

The QUAD module does not require any configuration. Continue to the **Verify Feedback** section on page 17.

Resolver Feedback

1. In the **Axis Parameters** pane, on the **Setup** tab, under **Primary Control Setup**, set each register listed below, for each axis.
 - **Resolver Resolution** – 14-bits or 16-bits
 - **Reference Frequency**
 - **Reference Amplitude**

Note: For help on these parameters, click the cell and press F1.

2. Click the **Download** button  to apply the changes to the RMC.
3. Continue to the **Verify Feedback** section on page 17.

Verify Feedback

1. In the **Axis Status Registers** pane, on the **All** tab, expand the **Feedback** section.

For secondary inputs, expand the **Pressure/Force/Accel Feedback** section.

Register	Axis0	Axis1
■ Status Bits	16#00000000	16#00000000
■ Error Bits	16#00000000	16#00000000
■ Feedback		
Actual Position (pu)	0.000	0.000
Actual Velocity (pu/s)	0.000	0.000
Actual Accel (pu/s ²)	0.0	0.0
Voltage (V)		
Counts (C)	0	0
Raw Counts (raw C)	0	0
■ Pressure/Force/Accel Feedback		
Actual Pressure (Pr)	0.000	
Actual Pressure Rate (Pr/s)	0.000	
Voltage (V)	0.000	
Raw Counts (raw C)	0	0
■ Control		

2. Depending on your feedback type, look at the **Counts**, **Volts**, or **Current** register. It may be changing slightly.
3. Use the Direct Output command to move the axis back and forth (as described in the **Test an Actuator** section).
4. As the axis moves, look for a corresponding change in the **Counts**, **Volts**, or **Current**. If it does not change smoothly, recheck the wiring, verify that the parameters on the **Setup** tab are correct, and check for smoothly changing **Counts**, **Volts**, or **Current** again.
5. Save the project and update Flash.


Step 9: Scale and Offset

The Scale and Offset parameters convert the Counts, Volts, or Current from the transducer into meaningful measurement units.

First, determine the approximate positions at either end of travel. This will help you verify later that you performed the procedure correctly.

To set the Scale and Offset:

1. Go to the **Axes Parameters** pane, **Setup tab**, **Tools**, and **Wizards** section.



2. Click **Launch** on the desired axis.
3. In the wizard, follow the directions. For help, press the **Help** button.

Tip: If the wizard does not work for your system, you can manually determine the Scale and Offset parameters. See the Scaling topic in the RMCTools help for details.

4. After completing the wizard, in the **Axis Parameters**, locate the **Display Units** parameter.

Select the desired display units. If you wish to use units that are not listed, choose **Custom**, then type up to 4 characters in the **Custom Units** parameter.



5. Click the **Download** button to apply the changes to the RMC. Remember to save your project and update Flash.

Step 10: Set the Output Polarity

The Actual Position, Pressure, Force, or Velocity *must increase* when the RMC applies a *positive* output voltage. If this condition is not met, you will not be able to perform closed-loop control.

1. Send the Direct Output command with a positive **Output** value that is large enough to move the axis.
2. On the **Basic** tab of the **Axis Status Registers** pane, observe the **Actual Position** and note whether it is increasing or decreasing:

Increasing

The Output Polarity is correct. Go to **Enable the Axes** below.

Decreasing

You must invert the Output Polarity:


- A. In the **Axis Parameters** pane, on the **Setup** tab, double-click the **Invert Output Polarity** parameter to set it.
- B. Click the **Download** button  to apply the change to the RMC.

Enable the Axes

In order to send motion commands other than Direct Output, the axes must be enabled after the RMC starts up.

1. In the Command Tool, in the **Cmd** box, type **Enable** and choose **Enable Controller (7)** from the list.
2. Click **Send**. All axes will be enabled.

Entering RUN Mode will also enable the axes.



Step 11: Tuning

In order to control an axis in a closed-loop, it must first be tuned. You can use autotuning or manually tune the axis.

Autotuning – Position Axes Only

Autotuning can be used for most position control axes.



1. Open Tuning Tools

On the **Tools** menu, click **Tuning Tools**.

2. Set Up Tuning Tools

Set up the buttons that you will use to move the axis back and forth after autotuning is complete.

- Click the first button labeled **[Click to set up]**.
- Enter a **Move Absolute** command with position, speeds, and acceleration values that will work for your system.
- Repeat for the other button, with a different position.




3. Start the Tuning Wizard


In the Tuning Tools, click **Tuning Wizard**.

4. Complete the Tuning Wizard

During the autotuning, the wizard will move the axis a short distance when you prompt it to.



- When the wizard is complete, the **Gain Calculator** will open. Use the slider bar to choose gains. Begin by pulling the slider close to the bottom, then click **Apply Gains**.



- Use the buttons you previously set up to move the axis back and forth. The plot will automatically be displayed.

Tip: To halt the axis, click the **Fault Controller**  button on the toolbar, or press Ctrl+K.

- If the Actual Position is not following the Target Position very well, pull the slider bar up, apply gains, and move the axis again. Repeat until the Actual Position tracks the Target Position very well.

Tuning With an Existing Plot

If the autotuning does not work for your system, you can use the Tuning Wizard with an existing plot.

- In the Tuning Tools, use the **Move** buttons to make moves and adjust the Proportional Gain until the axis has some control.
- Start the Tuning Wizard and choose **Use Existing Plot**. The Wizard will prompt you to choose one of the plots of the moves you made.
- When the wizard completes, use the Gain Calculator as described above.

Manual Tuning—Position, Pressure, or Force Axes

You can manually tune systems for which autotuning does not work.

For instructions:

4. On the **Help** menu, choose **Help Topics**.
5. On the **Index** tab, type **tuning** and double-click **about**.
6. The **Tuning Overview** topic describes tuning.

In the **Manual Tuning** section, choose a procedure. For most position control applications, choose **Tuning a Hydraulic Position Axis or Motor in Velocity Mode**. For pressure or force, choose the procedure that applies to your axis.

After tuning, save the project and update Flash.

Continuing the Motion Application

After setting up and tuning the RMC, it is ready to perform motion and be integrated into the rest of your application. The RMC has numerous features to assist you. The major components are listed here to guide you when continuing your motion application.

Commands

The RMC has a rich set of pre-programmed commands that perform anything from simple moves to complex motion to system control. For a list of all the commands, see the **Command List** topic in the RMCTools help.

User Programs

A User Program carries out simple or advanced sequences of commands on the RMC. This allows the RMC to respond to events within its control-loop time rather than the scan rate of a PLC or other host controller. It also reduces the PLC programming required.

A User Program consists of multiple steps linked together in sequences. Each step can issue any RMC command to one or several axes. The link types allow branching and looping, waiting for conditions, and many other features. Simple and complex mathematical operations are also possible in the user program.

A User Program runs on a *task*. Each task can run one user program at a time. The RMC150 has ten tasks. Therefore, an RMC150 controller may run up to ten User Programs simultaneously.

For details on creating and running User Programs, see the **User Programs** topic in the help.

Communications

Most PLCs or other host controllers can communicate with the RMC, which includes reading status, writing values, and sending commands to the RMC. The RMC150E supports Ethernet and PROFIBUS-DP.

See the **Communications** section of the RMCTools help for more detailed information.

Discrete I/O

Discrete I/O augments the communications of the RMC. Discrete I/O is often faster than the communications and is therefore well-suited for starting a sequence in the RMC at a specific time. See the **Discrete I/O** topic in the RMCTools help for details.

Variables

Variables help make the User Programs very flexible and easy to maintain. Variables can be used to effortlessly change programs and easily modify User Program parameters via a PLC. Variables can also be used to store data.

For details on using variables, see the **Variables** topic in the help.

Program Triggers

Use the Program Triggers to start User Programs based on conditions defined by the user. For example,

- Start a User Program by writing to an RMC variable from a PLC.
- Start a User Program when a discrete input turns on.
- Automatically start a User Program when the RMC starts up.
- When an error condition occurs, automatically start a User Program to handle it.

See the **Program Triggers** topic in the RMCTools help for details.

Diagnostic Tools

This section describes the main diagnostic tools of RMCTools that will aid you in monitoring and troubleshooting your system.

Plots

The RMC provides very flexible plotting capabilities. Virtually any register in the RMC can be plotted, and multiple registers may be plotted simultaneously. You can easily capture events with the plot trigger. For details on using plots, see the **Plots** topics in the help.

Event Log

The Event Log Monitor displays all events that have occurred in the controller, such as issued commands, changed parameters, and errors. The Event Log Monitor is an important aid in troubleshooting.

The Event Log can help you:

- Determine if a command was successfully issued. The entire command, with parameters, is displayed.
- Find out which, if any, error occurred.
- See where a command was issued from, for example, from a PLC, a User Program, or the Command Tool.

To open the Event Log:

- In the Project Pane, expand the controller, and double-click **Event Log** .

Note: The Event Log is very useful! When you don't know what happened, or why something did not happen, look at the Event Log.

Appendix A: Wiring

This appendix describes how to wire the RMC. Use the table below to find the wiring diagram you need. For communications wiring, consult the RMCTools help.

Note: Remove power from the RMC before connecting any wires.

Wiring Topic	Page	
General Wiring Information	27	
Power	28	
Control Output (Drive)	28	
SSI Inputs	29	
Start/Stop and PWM Inputs (Magnetostrictive)	31	
Analog Inputs	Voltage Transducer	33
	Potentiometer	34
	Current Transducer	34
Quadrature Inputs	35	
Resolver Inputs	36	
Discrete Inputs/Outputs	Discrete Outputs	37
	Discrete Inputs	38

General Wiring Information

To minimize electrical interference:

- Use twisted pairs for all wiring where possible.
- Use shielded cables for all wiring.
- Keep RMC wiring separate from AC mains or conductors carrying high currents, especially high frequency switching power such as conductors between servo drives and motors or amplifiers and proportional valves.

For UL and CUL compliance:

- Power supply must be Class 2.
- All RMC inputs and outputs must be connected to Class 2 circuits only.

For products labeled Class I, Division 2:

- Conductors must be copper only. Follow wire gauge and clamp screw torque as listed below.

Wire Gauge and Clamp Screw Torque

Use the table below to determine the proper wire gauge and torque for the clamp screws on the terminal blocks.

Module	Gauge	Torque
RMC150E, MDT (M), SSI (S), Analog (H, A, G), RES (R)	26-12 AWG (0.13 - 3.3 mm ²)	4.5 lb-in (0.51 Nm)
DI/O, UI/O	28-16 AWG (0.08 - 1.3 mm ²)	2.2 lb-in (0.25 Nm)

Wiring Power

Voltage: +24Vdc (20.4 – 27.6Vdc)


Current rating:

Backplane Slots	3	4	5	6
Max Current (mA)	375	500	625	750

UL and CUL Requirements


For UL and C-UL compliance, the power supply must be Class 2. Class 2 power supplies are limited to 100W output. No additional fusing is required if a class 2 power supply is used.

Power Wiring Diagram




Note: For optimum power stability, do not power high-current-draw devices with the same 24V power supply used for the RMC. The RMC may restart if it experiences a momentary power drop.

Control Output for all Axis Modules



SSI Transducer Wiring

For Synchronous Serial Interface (SSI) transducers and encoders.
If the SSI transducer is linear, make sure to choose the synchronized type.



Tip: See the next page for manufacturer-specific wiring diagrams.

Universal I/O Module:

The Universal I/O SSI input wiring is identical to the diagram shown above, with the exception of the pin order. For details, see the **UI/O Module Wiring** topic in the RMCTools help.

Notes:


- The user must supply power to the transducer.
- Do NOT connect the transducer ground or common to the shield, case, or protective earth ground

SSI Manufacturer-Specific Wiring Labels and Colors

These diagrams provide transducer manufacturer labels and colors.
Follow all SSI wiring instructions on page 29.


Balluff Micropulse BTL-5 with SSI output

Styles: Z, W, K, P




MTS Temposonics with SSI output

Models: R, RP, RH



MDT Module Start/Stop or PWM Transducer Wiring

For magnetostrictive transducers with Start/Stop or PWM outputs.



Tip: See the next page for manufacturer-specific wiring diagrams.

Notes:


- The MDT module interfaces to 5V differential (RS-422) signals. Single-ended (TTL) signals are strongly discouraged. See the RMCTools help for single-ended wiring diagrams.
- The user must supply power to the transducer.
- Do NOT connect the transducer ground or common to the shield, case, or protective earth ground.

MDT Manufacturer-Specific Wiring Labels and Colors

These diagrams provide transducer manufacturer labels and colors.
Follow all MDT wiring instructions on page 31.


Balluff Micropulse BTL-5, digital RS-485 output

Styles: Z, W, K, E, P, R, AT




MTS Temposonics with digital output (Start/Stop or PWM)

Models: LH, LS, LD, LF, LPS, LPR, G, EP2, ER




MTS Temposonics II with DPM or RPM personality module



Analog Voltage Transducer Wiring


Voltage Transducer, 4- or 5-Wire



To reduce electrical interference:


- **-In** and **Cmn** must be connected, either internal to the transducer or externally as close as possible to the transducer.
- Use individually shielded twisted-pair wire.
- Connect cable shield to earth ground on one end only.
- If transducer has only one common, connect Pwr Supply Common and RMC Cmn to it. For best results, make this connection at the transducer.

Voltage Transducer, 3-Wire



Potentiometer with Exciter Pin

Note: Use the **Exciter** pin to increase the measurement accuracy of the potentiometer. Not available on the UI/O module.




To reduce electrical interference:

- The connection of **-Analog In** to **Cmn** should be made as close as possible to the transducer.
- Use individually shielded twisted-pair wire.
- Connect cable shield to ground on one end only.


Analog 4-20mA

Note: The Analog (G) module does not support 4-20mA.



Quadrature Encoder Wiring

Pin-out table is available in the RMCTools help.



Universal I/O Module


The Universal I/O encoder wiring is identical to the diagram shown above, with the exception of the pin order. For details, see the **UI/O Module Wiring** topic in the RMCTools help.

Reg/Lim and Home Inputs

Compatible with 5-24Vdc. They draw 3.5mA min, 10mA max.

Resolver Module Transducer Wiring

The wiring diagram below is for resolvers that fall within the Resolver module's signal specifications (800Hz to 5kHz and 1.41 to 4.8VRMS). The Ref In input is only used for reference signals outside of these specifications and requires contacting Delta for assistance.



Pin	Function
R1	Reference Output +
Ref In	Reference In (normally not used)
R3	Reference Output -
S1	Sine Input +
S3	Sine Input -
S2	Cosine Input +
S4	Cosine Input -
Case	Controller Chassis Ground (shield)

Discrete Output Wiring


The discrete outputs on the RMC150E, DI/O, and UI/O modules are solid-state relays. When off, they have high impedance, and when on, they have low impedance.

	RMC150E	DI/O	UI/O
On Impedance		50Ω max, 25Ω typical	
Max Current		75mA (50mA for Class I Div 2)	75mA (Class I Div 2 not available)
Max Voltage	30V		

When switching *inductive* loads, place a diode or transorb across the load to protect the switch when it turns off. Otherwise, a voltage spike in excess of the 30V rating of the SSR may occur. See the **RMC150E Discrete I/O Wiring** topic in the RMCTools help for more details.


DI/O and UI/O Module

Outputs can be wired in either a high-side or low-side configuration. Because all the outputs share a common, all outputs on the same module must be wired the same.



RMC150E Module

Each output has a “+” and “–” connection. Outputs can be wired in either a high-side or low-side configuration.



Discrete Input Wiring


To turn on a discrete input, apply a voltage of the correct level. The polarity is unimportant.

	RMC150E	DI/O	UI/O
Signal Levels	12-24Vdc	5-24Vdc	12-24Vdc
Max Current Draw	3mA max	6mA at 5V 10mA at 24V	3mA max

DI/O and UI/O Module


Because all the inputs share a common, all inputs on the same module must be wired the same.

Example




RMC150E Module

Each input has a “+” and “-” connection.





Example



Appendix B: Mounting Dimensions

Backplane Slots	3	4	5	6
Total Width	4.10 in. (104.1 mm)	5.10 in. (129.5 mm)	6.10 in. (154.9 mm)	7.10 in. (180.3 mm)



Appendix C: Agency Compliance

UL and CUL

For UL and CUL compliance:

- Power supply must be Class 2.
- All RMC inputs and outputs must be connected to Class 2 circuits only.

Class I Div 2

Products marked “Class I Division 2, Group A, B, C, D” are suitable for use in Class I Division 2, Groups A, B, C, and D hazardous locations and nonhazardous locations only.

WARNING – EXPLOSION HAZARD – DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.

WARNING – EXPLOSION HAZARD – SUBSTITUTION OF ANY COMPONENT MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.

Surrounding air temperature of 60° C.

The RMC150E USB port is intended for configuration, programming, and troubleshooting purposes only. It should not be connected during normal operation.

See page 27 for wire gauge, screw clamp torque, and wire type requirements.

Notes

Connect. Control. Optimize.



DELTA
MOTION

deltamotion.com